
HYVA ALUMINIUM OIL TANKS

SIDE MOUNTED TANK INCLUDING SUPPORT





Part list				
Pos.	Part no.	Description	Qty.	
	140 18 200	Consisting of:		
1	081 02 116	air breather filter	1	
2	140 20 065	strap 1372 x 35 mm	2	
3	140 20 159	kit for single support	1	
4	140 20 345	tank support	1	
Spare Parts				
Pos.	Part no.	Description	Qty.	
5	081 02 117	air filter element	1	
6	081 02 121	spy glass	1	
7	020 52 431	cover plate	1	
8	020 52 432	gasket	1	

Optional part				
Part no.	Description	Qty.		
147 80 303	return filter kit	1		

General information

Pay attention to the following points:

- Mount the tank according the mounting instructions.
- Fill the tank with the recommended hydraulic oil to the centre of the spy glass (level indicator).
- · Change the oil once a year.
- Replace the air breather filter twice a year.
- Do not use the tank as a support or to stand on.
- Do not weld to the oil tank.

Specifications

Gross volume : 132 Liters
Fill volume : 122 Liters
Working volume : 110 Liters
Total weight : 32 kg

Connections : 1½" BSPIT (2x Suction) : ¾" BSPIT (Valve plate)

Subject to change without notice DO-E 14018200 / 15 08 21 / RV AE