HYVA ALUMINIUM OIL TANKS




SIDE MOUNTED TANK

Hyva


Page 1 / 1

type :

SM - 179L/150L - AL - MP - MR 140 18 228



150 liters



Part list

	-	• • • •	
Pos.	Part no.	Description	Qty.
	140 20 161	Mounting kit parts consisting of:	
1	081 02 116	air breather filter	1
2	140 20 300	straps	2
3	140 20 328	kit for two supports	1
4	140 20 321	tank support	2
Spare	Parts		
Pos.	Part no.	Description	Qty.
5	081 02 117	air filter element	1
6	081 02 121	spy glass	1
7	020 52 431	cover plate	1
8	020 52 432	gasket	1

Optional	part
----------	------

Part no. 147 80 303 Description return filter kit

General information

Pay attention to the following points:

- Mount the tank according the mounting instructions.
- · Fill the tank with the recommended hydraulic oil to the centre of the spy glass (level indicator).
- · Change the oil once a year.
- Replace the air breather filter twice a year.
- Do not use the tank as a support or to stand on.
- Do not weld to the oil tank.

Specifications

Qty.

Gross volume		179	Liters
Fill volume		165	Liters
Working volume		150	Liters
Weight tank		16	kg
Weight each support		10	kg
Connections		11⁄2"	BSPIT (Suction)
	:	3/4"	BSPIT (Valve plate)