
HYVA ALUMINIUM OIL TANKS

SIDE MOUNTED TANK



Hyva type: SM - 155L/129L - AL - MP2 - MR 140 18 227 part number tank: Page 1 / 1 129 liters working volume:



Pos.	Part no.	Description	Qty.
	140 20 161	Mounting kit parts consisting of:	
1	081 02 116	air breather filter	1
2	140 20 300	straps	2
3	140 20 328	kit for two supports	1
4	140 20 321	tank support	2
Spare	Parts		
Pos.	Part no.	Description	Qty.
5	081 02 117	air filter element	1
6	081 02 121	spy glass	1
7	020 52 431	cover plate	1
8	020 52 432	gasket	1

Description

return filter kit

Part no.

147 80 303

Gross volume
Fill volume
Working volum

Weight tank

Qty.

Specifications

General information

Pay attention to the following points:

• Replace the air breather filter twice a year. • Do not use the tank as a support or to stand on.

the spy glass (level indicator). · Change the oil once a year.

• Do not weld to the oil tank.

: 155 Liters : 140 Liters : 129 Liters : 15 kg Weight each support : 10

Mount the tank according the mounting instructions.

· Fill the tank with the recommended hydraulic oil to the centre of

BSPIT (Suction) Connections : 11/2" BSPIT (Valve plate 2x) : 3/4"

Subject to change without notice

DO-E 14018227 / 13 06 11 / RV AA