
HYVA ALUMINIUM OIL TANKS

SIDE MOUNTED TANK



Hyva $type: SM-179L/150L-AL-MP-MR \ double \ block \\ part \ number \ tank: 140\ 18\ 229 \\ Page 1/1 \qquad working \ volume: 150 \ liters$



Pos.	Part no.	Description	Qty.
1	140 20 161 081 02 116	Mounting kit parts consisting of: air breather filter	1
2	140 20 300	straps	2
3	140 20 328	kit for two supports	1
4	140 20 321	tank support	2
Spare	Parts		
Pos.	Part no.	Description	Qty.
5	081 02 117	air filter element	1
6	081 02 121	spy glass	1
7	020 52 431	cover plate	1
8	020 52 432	gasket	1

Description

return filter kit

Part no.

147 80 303

General information

Pay attention to the following points:

- Mount the tank according the mounting instructions.
- Fill the tank with the recommended hydraulic oil to the centre of the spy glass (level indicator).
- · Change the oil once a year.
- Replace the air breather filter twice a year.
- Do not use the tank as a support or to stand on.
- Do not weld to the oil tank.

Specifications

Qty.

Gross volume : 179 Liters
Fill volume : 165 Liters
Working volume : 150 Liters
Weight tank : 17 kg
Weight each support : 10 kg

Connections : 1½" BSPIT (Suction) : ¾" BSPIT (Valve plate 2x)

Subject to change without notice DO-E 14018229 / 12 11 23 / RV AD